REPAIR PARTS

STANDARD CONTROL BOX			
ITEM	PART NUMBER	DESCRIPTION	
1	K74-39307-1	Standard Plastic Control Box Only	
2	K76-36296-1	Outlet	
3	K75-36635	Control Board Bracket	
4	K1D8388-1CC	Control Board	
5	K1D8387-1CC	Expansion Board	
6	K94-36411	Piezo Alarm	
7	K94-36408-1	Reset Switch with Product ID	
8	K74-36596	Batteries (2) with jumper	
9	LA500HDTKITSTD	Toroidal Transformer	
10	29-NP712	Single Battery	
NOT SHOWN			
	K77-36541	Antenna	
	LA500CONTUL	Standard Plastic Control Box (with control board)	
	K94-36274-2	J15 Harness	
	K94-36274-2	Wire harness between main control board and expansion board	
	XLSOLARCONTUL	Solar box for LA412U, LA400, LA500U	

GATE OPERATOR ARM		
ITEM	PART NUMBER	DESCRIPTION
11	LA500DC	Primary Arm
12	KSWG-0623	Rear Connector with Pin
13	41ASWG-0119	Release Keys
14	Q230	Steel Bracket Mounting Plates
15	Q232	Bottom Washer and Nut
16	K94-36591	Junction Box with Cable
NOT SHOWN		
	K77-36389	Hardware Bag

